

GND			pin#14		
Power(Vcc)			LED#1	pin#1	
Keepalive reset					PB7
PLT		TR#1	LED#2	pin#10	PB6
Keepalive PLT			LED#3	pin#9	LED ext drive
	Light	TR#2	LED#4	pin#8	PA6
A/D power		TR#3	LED#5	pin#7	PA5
SSR	Solenoid#1	TR#4	LED#6	pin#6	PA4
	Solenoid#2	TR#5	LED#7	pin#5	PA3
	Solenoid#3	TR#6	LED#8	pin#4	PA2
	Ext.AC	TR#7	LED#9	pin#3	PA1
		TR#8	LED#10	pin#2	PA0

SSR：ソレノイドx3　LAN機器ACコンセント　照明　＝5

TR：オペアンプ

温度計